

Majacraft Universal Lazy Kate Assembly

General Description

The Universal Lazy Kate is a three bobbin tensioned Lazy Kate that will hold any Majacraft bobbin.



Box Contents


- Universal Lazy Kate with tensioned feet
- 3 brass bobbin bars
- 1 wooden tension knob
- 1 tension cord and tension spring attached to a closed ring cup hook
- 2 closed ring cup hooks

Assembly Instructions


1. Carefully tap the three yarn guides into the holes in the top of the Lazy Kate.
2. Screw the cup hook that is attached to the tension spring into the small right-most hole in the face of the Lazy Kate
3. Screw the remaining two cup hooks in the small holes in the face of the Lazy Kate.
4. Thread the brake band through the other two hooks.
5. Push the tension knob into the left-most hole and then tie the end of the brake band to the tension knob through the small hole in the aluminium shaft.
6. Push the brass rods into the remaining three holes of your Lazy kate.

Configuration 1 is generally more suited for plying bobbins.

Configuration 2 is generally more suited for standard and lace size bobbins.



Configuration 1



Configuration 2

majacraft